

NARVA®

ALS®

ADVANCED LIGHTING SYSTEMS

Part No. 71460 & 71462

NARVA ALS INSPECTION LAMPS

INSTRUCTIONS



PATENT
PENDING

Part No. 71460

200lm rechargeable LED Inspection Light

High efficiency COB LED
Front: 200 lumen
Top: 100 lumen
2.5h/3h operating time
(step front/top)
2-3h charging time
3.7V 1200mAh Li-poly battery
IP65

Part No. 71462

500lm rechargeable LED Inspection Light

High efficiency COB LED
Front: 250/500 lumen (step 1/2)
Top: 150 lumen
5h/2.5h/5h operating time
(step front 1/2/top)
2-3h charging time
3.8V 3000mAh Li-ion battery.
IP65

Flashlight function



150
LUMEN

30°

25m

Glow-in-the-dark locator



IP65 dust and water resistant




Fuel gauge



Heavy-duty mounting magnet



180° rotating bracket



FEATURES

High Efficiency LED

- Dual light source – front COB LED and top SMD LED.
- COB LED provides 50% and 100% brightness (for model 71462 only).
- Top SMD LED lamp can be used as a flashlight for narrow work areas.

Brightness Memory Function

- Setting is recorded after 5 seconds of activation.
- Recorded setting is recalled next time the device is activated.

Multi-Functional Design

- Flexible 180 degree bracket.
- Heavy-duty mounting magnet.
- Flush mounted hook can be rotated for hanging and carrying.
- Glow-in-the-dark fluorescent reflector makes them easy to find in the dark.
- The light will flash as a low power warning prior to the battery running out.
- 71462 includes charging base with magnet and mounting holes (screws included).

USAGE INSTRUCTIONS

71460

- Before using, plug the adapter into any 240V AC standard power source to let unit fully charged until the white LED indicators at the back of light all light up.
- Press the switch continuously for changing steps of light sources (cyclic steps: top LED-front LED-off). Press and hold the switch 1.5 seconds to check the battery capacity status.

71462

- Before using, put the light into charging base and plug the adapter into any 240V AC standard power source to let unit fully charge until the five white LED indicators at the front of light all light up.
- Press the switch continuously for changing steps of light sources (cyclic steps: top LED-front LED dim-front LED bright-off). Press and hold the switch 1.5 seconds to check the battery capacity status.

WARNINGS AND CAUTIONS

- Please read and understand this instruction carefully to ensure the safe and effective use of this light. And follow all directions before using.
- Risk of electrical shock, do not use in the environment with gas, combustible or explosive materials, hot objects.
- Keep away from the reach of children.
- Do not open, repair or modify.
- Do not use the light with wet hand.
- Use only under the recommended voltage and frequency requirements.
- To avoid the harm to your eyes, please do not look straight to the light.
- Minimum distance from lighted objects 0.1m.
- Please use standard 5V 1.5A adapter to charge the light.
- The specification in this manual is based on standard lab testing, different environment may influence the data.
- Charge this light every 3months if not in constant use, and after each use, if it is used often to ensure longevity.
- The battery is not replaceable.

WARRANTY

Warranty for 2 years from the original purchase date.

THIS WARRANTY DOES NOT COVER BATTERY OR ACCESSORIES NOR DEFECTS OR DAMAGES TO THE LIGHT (I) after the warranty period expires; (II) resulting from misuse or abnormal operation; (III) resulting from a failure to properly maintain or operate the tool; or (IV) resulting from any repair or maintenance services performed by any party other than Narva.

Distributed by:

Brown & Watson Int. Pty Ltd

Ferntree Gully Road

Knoxfield, Victoria 3180

www.narva.com.au

IS399 Issue 1

22.08.18