

NARVA®

INSTRUCTION SHEET

P/No. 87780, 87780BL, 87786, 87788



L.E.D Awning Lamp

INSTALLATION INSTRUCTIONS


- Remove white casing from lamp assembly by unclipping from the points (diagram 1).
- Drill a 10mm pilot hole to suit the cable exit.
- Drill 2 x 3mm pilot hole to suit screws.
- Install screws or rivets and secure base to mounting surface (diagram 2).
- Clip white cover back onto base.




Diagram 1



Diagram 2



P/No. 87780 & 87780BL



P/No. 87786 & 87788

PIR (Passive Infrared) Sensor Adjustment (P/No. 87788 only)

The PIR will activate the lamp when it senses movement within a 3 metre radius from the sensor. The PIR function can be adjusted to maintain lamp illumination between 1 sec & 1 min using the dial on the base of the unit (diagram 3).

Note: PIR sensor will only activate lamp in dark conditions.





Diagram 3

WIRING INSTRUCTIONS (P/No. 87780, 87780BL, 87786)

Red: Positive (+)
Black: Negative (-)

WIRING INSTRUCTIONS (P/No. 87788 only)

Red: Positive (+)
Black: Negative (-)
White (PIR): Positive (+)



3 Way Switch Wiring Option:

When wiring the PIR Awning Lamp (P/No. 87788) a 3 way switch can be used to allow the lamp to be turned on/off permanently. As well as switching the PIR function on separately, the lamp will then only illuminate when the PIR sensor is activated.

Note: The following Narva 3 way switches are suitable for this type of application: 62011BL, 63041BL (Rocker Switches) & 60061BL (Toggle Switch).

Distributed by:

Brown & Watson Int. Pty Ltd

Ferntree Gully Road

Knoxfield, Victoria 3180

www.narva.com.au

WARRANTY STATEMENT

Applicable only to product sold in Australia

Brown & Watson International Pty Ltd of 1500 Ferntree Gully Road, Knoxfield, Vic., telephone (03) 9730 6000, fax (03) 9730 6050, warrants that all products described in its current catalogue (save and except for all bulbs and lenses whether made of glass or some other substance) will under normal use and service be free of failures in material and workmanship for a period of one (1) year (unless this period has been extended as indicated elsewhere) from the date of the original purchase by the consumer as marked on the invoice. This warranty does not cover ordinary wear and tear, abuse, alteration of products or damage caused by the consumer.

To make a warranty claim the consumer must deliver the product at their cost to the original place of purchase or to any other place which may be nominated by either BWI or the retailer from where the product was bought in order that a warranty assessment may be performed. The consumer must also deliver the original invoice evidencing the date and place of purchase together with an explanation in writing as to the nature of the claim.

In the event that the claim is determined to be for a minor failure of the product then BWI reserves the right to repair or replace it at its discretion. In the event that a major failure is determined the consumer will be entitled to a replacement or a refund as well as compensation for any other reasonably foreseeable loss or damage. This warranty is in addition to any other rights or remedies that the consumer may have under State or Federal legislation.

IMPORTANT NOTE

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.