

NARVA®

INSTRUCTION FOR ALL


MODEL 43 COMBINATION LAMPS




INSTALLATION OF LAMP HOUSING

- Determine if you are fitting housing to L/H or R/H side of the vehicle, refer to drawings below for correct orientation of housing and cable exit position before drilling.
- Drill a \varnothing 10mm hole to suit the cable exit (excluding connectors).
- Drill 4 x \varnothing 6mm pilot holes to suit screw/rivet installation or 2 x \varnothing 8mm pilot holes for bolt installation depending on the application.
- Install screws/rivets or bolts and secure lamp housing to vehicle

LH Assembly




RH Assembly




SNAP LAMPS INTO BASE

- Place the bottom of the lamp into the housing, ensure the lamp is positioned so the word 'TOP' located on the lamp is facing towards the top of the housing.
- Push top of lamp inward until it 'snaps' into place.



SNAP REFLECTORS INTO BASE

- Reflectors are to be mounted at each end of the housing over mounting points.
- Insert reflector with mounting tabs facing the centre of the housing
- Once tabs are in position, push firmly and evenly on both sides of the reflector and snap firmly into housing.




WIRING INSTRUCTIONS


White: Earth (-)	Red: Stop (+)
Brown: Tail (+)	Green: Indicator (+)
Black: Reverse (+)	Yellow: Indicator (+)

LAMP REMOVAL

- To remove lamp, insert a flat device (e.g. screw driver) between lamp and housing as marked on lamp. Carefully pivot device upwards until the lamp releases from the base.



- To remove reflector pull upwards on the lip located on the outer edge of the reflector.



Distributed by:

Brown & Watson Int. Pty Ltd

Ferntree Gully Road
Knoxfield, Victoria 3180

www.narva.com.au

WARRANTY STATEMENT

Applicable only to product sold in Australia

Brown & Watson International Pty Ltd of 1500 Ferntree Gully Road, Knoxfield, Vic., telephone (03) 9730 6000, fax (03) 9730 6050, warrants that all products described in its current catalogue (save and except for all bulbs and lenses whether made of glass or some other substance) will under normal use and service be free of failures in material and workmanship for a period of one (1) year (unless this period has been extended as indicated elsewhere) from the date of the original purchase by the consumer as marked on the invoice. This warranty does not cover ordinary wear and tear, abuse, alteration of products or damage caused by the consumer.

To make a warranty claim the consumer must deliver the product at their cost to the original place of purchase or to any other place which may be nominated by either BWI or the retailer from where the product was bought in order that a warranty assessment may be performed. The consumer must also deliver the original invoice evidencing the date and place of purchase together with an explanation in writing as to the nature of the claim.

In the event that the claim is determined to be for a minor failure of the product then BWI reserves the right to repair or replace it at its discretion. In the event that a major failure is determined the consumer will be entitled to a replacement or a refund as well as compensation for any other reasonably foreseeable loss or damage.

This warranty is in addition to any other rights or remedies that the consumer may have under State or Federal legislation.

IMPORTANT NOTE

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.