

Part No. 74428


EX2 - WIRING HARNESS NEXT GEN FORD RANGER

INSTRUCTIONS AND SPECIFICATIONS



IMPORTANT SAFETY INFORMATION

- Remove negative battery cable before installation
- Ensure the lamps are mounted securely to a solid surface on the vehicle or bullbar
- Cables connected to the lamp must not be subjected to wear or other damage




WIRING INSTRUCTIONS

EX2 NEXT GEN FORD RANGER INSTALLATION

- This harness has been designed to fit NARVA EX2 Driving Lights (and Light Bars) to Next Gen Ford Ranger vehicles with the Level 2 Headlight fitted. The high beam signal wire in these models is located in the front passenger side footwell, behind the left side kick panel (interior trim). Refer to the vehicle manual for further details. The wire is labelled "HIGH BEAM" and requires the supplied male QC connector to be added.
- 2. Fit harness lead with female QC connector labelled "TO HIGH BEAM SIGNAL WIRE" through appropriate grommet in vehicle firewall on passenger side of the vehicle. This is to be connected to the male QC connector fitted in the passenger footwell in Step 1. This lead has a 2Amp blade fuse fitted. Make sure this is accessible. The kick panel can now be re-fitted.
- 3. The mouse switch connector (harness side) also needs to be fitted through vehicle firewall. This can fit through the same grommet as per Step 2. The supplied mouse switch is long enough to fit behind the dashboard, allowing the mouse switch to be mounted on the vehicle dashboard.
- 4. Connect the mouse switch to the harness and mount to the vehicle dashboard in the desired position.
- 5. Once the EX2 lamps (or Lightbar) are securily fitted to the vehicle, using the supplied crimp joiners, attach the lamps to the harness. These are colour coded red, yellow and black. Connect red to red, yellow to yellow and black to black. A standard insulated terminal applicator/crimper is required to perform this task. A heatgun/lighter is also required to shrink the heatshrink once crimped. This will ensure a weatherproof connection.
- 6. Connect the cable lug labelled "GROUND" to either the negative (black) post on the vehicle battery or fit to an appropriate grounding point.
- 7. Connect the cable lug labelled "12V+VE" to the positive (red) post on the vehicle battery.
- 8. The lamps can now be tested by starting the vehicle, switching on the High Beam lamps then pressing the button on the mouse switch. If the EX2 lamps power on, the installation is complete.

LAMP WIRING (WITH SWITCH)



WARRANTY STATEMENT

Brown & Watson International Pty Ltd ("BWI") of 1500 Ferntree Gully Road, Knoxfield, Vic., telephone (03) 9730 6000, fax (03) 9730 6050, warrants that all products described in its current catalogue will under normal use and service be free of failures in material and workmanship for a period of seven (7) years from the date of the original purchase by the customer as marked on the invoice. This warranty does not cover ordinary wear and tear, abuse, alteration of products or damage caused by the purchaser. To make a warranty claim the consumer must deliver the product at their cost to the original place of purchase or to any other place which may be nominated by either BWI or the retailer from where the product was bought in order that the warranty assessment may be performed. The consumer must also deliver the original invoice evidencing the date and place of purchase together with an explanation in writing as to the nature of the claim. In the event that the claim is determined to be for a minor failure of the product then BWI reserves the right to repair or replace it at its discretion. In the event that a major failure is determined the consumer will be entitled to a replacement or a refund as well as compensation for any other reasonably foreseeable loss or damage. This warranty is in addition to any other rights or remedies that the consumer may have under State or Federal legislation.

IMPORTANT NOTE

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Distributed by AUSTRALIA OFFICE Brown & Watson International Pty. Ltd.

Knoxfield, Victoria 3180 Phone: (03) 9730 6000 Fax: (03) 9730 6050 National Toll Free: 1800 113 443 NEW ZEALAND OFFICE Brown & Watson International NZ Ltd. Mount Wellington, Auckland 1060

Phone: (09) 525 4575

IS669 Issue 1 03.07.25