


# NARVA®

Part No.74405-1

## 8" ULTIMA LIGHT BAR PAIR WIRING HARNESS WIRING INSTRUCTIONS



- 1 Connect Loom 'B' 4PIN DT to both 8" lightbar DT socket.
- 2 Fix Loom 'B' ground cable to chassis or battery(-).
- 3 Connect Loom 'A' to Loom 'B'.
- 4 Mount relay and fuse holder (Ensure these are mounted in a dry area of the engine bay)
- 5 Connect main positive cable from fuse holder to battery (+).
- 6 The kit is supplied with a pre-wired H4 & HB3 loom assembly for direct connection to the vehicle headlamp high beam circuit. For globe types other than H4 & HB3, an additional adapter kit (Narva P/No. 74416) is available to suit H1, H3 and H7 globe types.
- 7 A direct connection from the vehicle high beam circuit to any alternate light source can be made by connecting the black wire to negative and red wire to positive.
- 8 Pass Loom 'A' 3core lead through the firewall and connect to Driving Lamp Switch.
- 9 Test the driving lights by turning on the vehicle's headlamps and park light. The driving lights should only illuminate on high beam.

**Note:** Driving lights must dip with H/Beam to meet ADR requirements

Use of Non-Narva high beam adapters can cause short circuit

**Note: "High Beam Splitter" included if multiple wiring harnesses are used and require high beam feed.**

**4PIN DT Wire Specification (1 x 8" Lightbar):**

PIN 1: Positive Red 4MM (16AWG)

PIN 2: Negative Black 4MM (16AWG)

PIN 3: BLANK

PIN 4: Linbus White 2.5MM (20AWG)

For pair:

Join both "Positive" to 5MM cable and both "Negative" to 5MM cable

**WARRANTY STATEMENT**

Brown & Watson International Pty Ltd ("BWI") of 1500 Ferntree Gully Road, Knoxfield, Vic., telephone (03) 9730 6000, fax (03) 9730 6050, warrants that all products described in its current catalogue will under normal use and service be free of failures in material and workmanship for a period of one (1) year from the date of the original purchase by the customer as marked on the invoice. This warranty does not cover ordinary wear and tear, abuse, alteration of products or damage caused by the purchaser.

To make a warranty claim the consumer must deliver the product at their cost to the original place of purchase or to any other place which may be nominated by either BWI or the retailer from where the product was bought in order that the warranty assessment may be performed. The consumer must also deliver the original invoice evidencing the date and place of purchase together with an explanation in writing as to the nature of the claim.

In the event that the claim is determined to be for a minor failure of the product then BWI reserves the right to repair or replace it at its discretion. In the event that a major failure is determined the consumer will be entitled to a replacement or a refund as well as compensation for any other reasonably foreseeable loss or damage.

This warranty is in addition to any other rights or remedies that the consumer may have under State or Federal legislation.

**IMPORTANT NOTE**

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

**Distributed by**

**AUSTRALIA**

**Brown & Watson International Pty. Ltd.**

Knoxfield Victoria 3180

Phone: (03) 9730 6000

Fax: (03) 9730 6050

National Toll Free: 1800 113 443

**NEW ZEALAND OFFICE**

**Griffiths Equipment Ltd.**

19 Bell Avenue,

Mount Wellington,

Auckland 1060, New Zealand

Phone: (09) 525 4575

IS530

Issue 1 21/02/23